


tedee

INSTALLATION GUIDE AND USER MANUAL

tedee nordic adapter




Read installation guide and user manual and learn how to assemble the adapter in a safe and proper manner.

table of contents

■ table of contents	Page 2
quick start with tedee nordic adapter	Page 3
set of items – what's in the box?	Page 4
■ what's NOT in the box (but is needed)?	Page 5
■ setup – 3 easy steps	Page 6
step 1: PREPARE your door	Page 6
step 2: INSTALL the adapter	Page 12
step 3: INSTALL tedee lack	Page 15
additional and technical information	Page 20
■ technical information	Page 20
technical support	Page 20

quick start with tedee nordic adapter



Tedee nordic adapter can be fitted to any door equipped with a lock that works with Scandinavian profile cylinders.

It's a part of tedee set. It's customized for tedee lock to make your door smart.

This booklet will give you an overview of the basic features of tedee nordic adapter and will help you walk through the setup in 3 easy steps.

tedee nordic adapter setup - go to page 6

3 easy steps




PREPARE your door


INSTALL the adapter INSTALL tedee lock

set of items - what's in the box?

tedee nordic adapter



tailpiece with cam



- other items





- 1. Lock stabilizer
- 2. Mounting holes
- 3. Adapter shaft

- 4. Groove and hole
- **5.** Cam
- 6. Tailpiece

- 7. Plate
- 8. Plate mounting
 - screws (2x)

what's NOT in the box (but is needed)?

necessary to prepare

step 1 and step 2



TIME (15-30 MIN)



RULER



PHILLIPS SCREWDRIVER



2x PLIERS






TEDEE LOCK




ALLEN KEY

step 1: PREPARE your door

1 Remove the mounting screws that keep your old knob escutcheon in the door lock.




2 Remove the old knob escutcheon from the door lock.





Note: the lock escutcheon on the other side of the door is fixed with the screws you just removed. Make sure to prevent it from falling off either with a tape, or just hold it with your hand.

Please, check if the tailpiece sticks out from the door leaf. Measure it with a ruler.






If it's between 3mm and 12mm, proceed directly to step 2.

If it's less than 3mm you should remove the tailpiece and replace it with a new one provided in the tedee nordic adapter box. Check the next pages to learn how to do it.

If it's more than 12mm you should shorten the tailpiece using pliers. Check the next pages to learn how to do it.




[OPTION A] If tailpiece sticks out less than 3mm



Replace the old tailpiece with a new one from the tedee nordic adapter box.

Then place back the plate (old or a new one) and secure it with the mounting screws.






 $\begin{tabular}{ll} \textbf{Note:} & please measure the tailpiece once again and make sure that your it sticks out from the door leaf more than 3mm but less than 12 mm. \end{tabular}$

If it does, proceed to step 2.

> 12 mm

[OPTION B] If tailpiece sticks out more than 12mm

- 1 Remove mounting screws that hold the plate, then remove the plate and the old tailpiece (follow the steps shown on the previous pages).
- Use two sets of pliers to adjust the length of your tailpiece.






Note 1: If you accidentally damage the tailpiece or shorten it too much, you can use the extra tailpiece provided in the tedee nordic adapter box.

Note 2: please measure the tailpiece once again and make sure that it sticks out from the door leaf more than 3mm but less than 12mm.


If it does, proceed to step 2.

step 2: INSTALL the adapter

1 Insert your tedee nordic adapter.



Mount the adapter with two screws using a Philips screwdriver.



Congratulations, your nordic adapter is now ready to host tedee lock.






Note: before proceeding to step 3 described on the next pages, please read tedee lock installation guide and user manual and learn how to use your device in a safe and proper manner. **When you're ready, proceed to step 3.**

step 3: INSTALL tedee lock


Align tedee lock with the shaft of the adapter and push it forward.

IMPORTANT: the mounting screw that extends from the lock mounting hole must fit into the groove on the adapter shaft.






Note: double check if tedee lock rear wheel is fully adjusted and fits the adapter's lock stabilizer. The lock is mounted correctly if the wheel remains in a fixed position when you rotate the lock manually.



2

Fix tedee lock tightly on the adapter using the Allen key provided in tedee lock box.






Note 1: Fix tedee lock tightly on the adapter. Keep rotating the key until it stops (at least two full turns).



Note: before turning on tedee lock make sure you read tedee lock installation guide and user manual and learn how to use your device in a safe and proper manner.






Note: after the RED-BLUE-GREEN-WHITE sequential light signal your tedee lock is ready to be added and calibrated in the app.

5 Download tedee app, create new account, and log in as described in step 2 of tedee lock installation guide and user manual.













Note: tedee lock which is not added to any account may turn off after a few minutes. If it does so, please turn it on again before starting the calibration.



6 Use tedee app to activate and calibrate your tedee lock as described in step 3 of tedee lock installation guide and user manual.



Note: follow instructions in tedee lock installation guide and user manual (step 2 and step 3).

additional and technical information

technical information

tedee nordic adapter

Models	Nordic-type door lock adapter
Variants	tailpiece with cam
Manufacturer	GERDA Sp. z o.o. ul. Sokołowska 49, 05-806 Komorów, POLAND +48 (22) 329 10 30, www.gerda.pl

technical support



For technical support please contact our support team



support@tedee.com



www.tedee.com/support



(+48) 884 088 011 Mon-Fri 8am – 4pm (CET)

tedee

Tedee Sp. z o.o. | ul. Altowa 2, 02-386 Warszawa, POLAND www.tedee.com | support@tedee.com